

# ENGLISH

## Instructions for V3,8

(red logging)



### Getting started

- 1 Package contents: **CAVIUS** device, carabina, strap and O-ring.
- 2 Slide off stainless steel tube.
- 3 Remove separation contact-tab between battery and contact point (Fig. 1). An internal system check will occur.
- 4 Slide O-ring provided over steel tube (Fig.2)
- 5 Replace steel tube, insert strap into cavity and slide o-ring back into strap cavity (Fig. 2). Attach carabina.



Emergency alarm **red** LED

Smoke detector **yellow** LED

Movement alarm **green** LED



### Alarm test

- 1 Hold down function button **[+]** for 2 seconds, alarm will sound.
- 2 Hold down function button **[+]** for 2 seconds, alarm will turn off

**Warning:** Do not place the device within 25 cm of ears as it could cause hearing damage

1

### EMERGENCY ALARM



x1 hold down for 2 seconds

1

### EMERGENCY ALARM



#### Activate Alarm **[ON]**

Hold down function button **[+]** for 2 seconds, alarm will sound.

#### Deactivate Alarm **[OFF]**

Hold down function button **[+]** for 2 seconds, alarm will turn off

2

### OPTICAL SMOKE DETECTOR



x2 in quick succession

2

### OPTICAL SMOKE DETECTOR



#### Activate Detector **[ON]**

Press function button **[+]** 2 times in quick succession. Smoke detector activation LED will flash yellow. Smoke detector is armed after 10 seconds.

Smoke detector function can be activated in conjunction with Movement alarm.

#### Deactivate Smoke Detector **[OFF]**

Press function button **[+]** 2 times in quick succession. Smoke detector activation LED [yellow] will stop flashing. Smoke detector is deactivated

3

### MOVEMENT ALARM



x3 in quick succession

3

### MOVEMENT ALARM



#### Activate Movement Alarm **[ON]**

Press function button **[+]** 3 times in quick succession. Movement alarm activation green LED will flash. Bag alarm is armed after 15 seconds.

- Place **CAVIUS** within 10seconds. If movement occurs a warning tone will be emitted. If movement continues for more than 3 seconds the alarm will sound. If movement stops within 5 seconds warning tone will cease

**Disarm Movement Alarm **[OFF]**** Press function button **[+]** 3 times in quick succession. Movement alarm activation LED [green] will stop flashing. Movement alarm is deactivated

**Place on its side**

### CAVIUS Smoke Detector Advice

The primary job of a smoke detector is to awaken sleeping persons and warn them of urgent danger - smoke detectors can not help you if they are not activated or are placed incorrectly.

Where to place your **CAVIUS** smoke detector depends on the size and layout of your room.

For optimum performance when using a smoke detector, place as high as possible and have as much free space around the unit as possible.

Optimum positions include; suspending **CAVIUS** from the ceiling or lying **CAVIUS** on its side at the base of the door

Do not put **CAVIUS** within six inches of where walls and ceilings meet, or near heating and cooling ducts. Smoke detectors located in these areas may not receive the flow of smoke required to activate the alarm.

Do not place the unit inside a bag and expect the smoke detector to operate. Instead place it externally, lying **CAVIUS** down on the floor in front of the door to enable both movement and smoke alarms to function.

Due to the portable nature of this product, Travelsafe cannot guarantee the smoke detector will operate if not placed correctly or if the unit is not maintained as mentioned below.

**CAVIUS** is designed to offer an extra level of fire security. It is a supplement to the permanent fire protection that should be provided at the location. Remember at all times to locate fire exits and to read the fire safety policy provided at your accommodation.

### CAVIUS Maintenance

**CAVIUS** does not require extensive maintenance. Simply initiate a systems test regularly (see below) and vacuum smoke chamber occasionally.

### CAVIUS Internal System Test

**CAVIUS** has the ability to carry out an internal systems check on all the components and functions. While inserting the battery: **CAVIUS** will emit a short beep and all 3 LEDs will flash 3 times. If this occurs **CAVIUS** is ready to use.

### Low Battery Warning Tone

**CAVIUS** will emit a warning tone when the battery is low. This will continue every minute until the battery is depleted.

### General

- If Movement alarm sounds while user is not around, the alarm will deactivate itself after 2 minutes and automatically return to an armed state. The green LED will then flash continually to inform the user of activation.
- When activated the selected alarms LED will flash every 30 seconds.
- The Smoke detector can be activated with the Movement alarm.
- We recommend always placing **CAVIUS** on its side when using the Movement alarm or Smoke detector.



Fig. 1



Fig. 2